


**BPW Suspension AL2**  
Part Identification



**BPW Suspension AL2 - Parts List**

<b>Item</b>	<b>Description</b>	<b>OE Part No</b>	<b>airsprings.com Part No</b>
1	Spring	05.082.13.88.0	<b>15199</b>
2	Bush	02.031.59.80.0	<b>50317</b>
3	Locking plate	05.348.30.37.0	<b>50361</b>
4	Spring pads, right	05.032.21.18.0	<b>50362</b>
5	Spring pads, left	05.032.21.19.0	<b>50363</b>
6	Spring plate	03.145.22.77.0	<b>50364</b>
7	Segment	03.345.23.09.0	<b>50232</b>
8	Bolt	03.084.74.43.0	<b>50100</b>
9	U-Bolt	03.138.37.02.4	<b>50318</b>
10	Disc	02.540.12.30.7	<b>50365</b>
11	Lock Nut	03.260.04.19.0	<b>50231</b>
12	Spring Bolt	03.341.05.05.0	<b>50366</b>
13	Plate (adjusting plate) Adjustment with sloted bush	03.281.54.18.0	<b>50367</b>
14	Disc	03.320.34.53.0	<b>50368</b>
15	Lock Nut	03.260.15.01.0	<b>50189</b>
16	Shock Absorber	02.372.21.40.0	<b>53014</b>
17	Hexagon screw	03.340.14.19.0	<b>50369</b>
18	Lock Nut	02.522.07.41.2	<b>50219</b>
19	Hanger bracket	05.375.44.02.0	<b>50370</b>
20	Shaped Plate	03.164.35.02.0	<b>50371</b>
21	Bush Adjustment with sloted bush	03.113.23.01.0	<b>50372</b>

**airsprings.com contact:**
**UK** +44 (0) 1925 810 400

**Ireland** +353 (0) 45 875 996

**(NI)** +44 (0) 2890 740 055

**Poland** +48 (0) 785 875 996

**airsprings.com**

International Parts Distributors