



Item	Description	PTL19-105	PTL21-105	PTL23-105	PTL27-105
1	Hanger Bracket PTL	<b>12458 LH</b>	<b>13040 LH</b>	<b>12455 LH</b>	<b>12453 LH</b>
1	Hanger Bracket PTL	<b>12457 RH</b>	<b>13041 RH</b>	<b>12456 RH</b>	<b>12454 RH</b>
2A	Beam Spring LH	<b>11380A</b>	<b>11380A</b>	<b>11380A</b>	<b>11380A</b>
2B	Beam Spring RH	<b>11381A</b>	<b>11381A</b>	<b>11381A</b>	<b>11381A</b>
6	Axle Saddle	<b>13039</b>	<b>13039</b>	<b>13039</b>	<b>13039</b>
7	U-Bolt	<b>13033</b>	<b>13033</b>	<b>13033</b>	<b>13033</b>
10	Locator Plate 25mm	-	-	-	-
11A	Assy Clip Plate RH	<b>13129</b>	<b>13129</b>	<b>13129</b>	<b>13129</b>
11B	Assy Clip Plate LH	<b>13128</b>	<b>13128</b>	<b>13128</b>	<b>13128</b>
12	Shock Absorber PTL	<b>13050SV</b>	<b>13050SV</b>	<b>13050SV</b>	<b>13050SV</b>
18	Air Spring	<b>16120</b>	<b>16120</b>	<b>16120</b>	<b>16120</b>
24	Top Plate Airspring / Pedestal Discs	<b>12160</b>	<b>12160</b>	<b>13113</b>	<b>13114</b>
25	Serial No. Plate Suspension	-	-	-	-
26	Drive Screw	-	-	-	-
	10mm Pushin Blanking Plug	-	-	-	-
	Male Stud 1/4" NPT - 10mm Tube	-	-	-	-
	Bolt Kit for PTL	<b>B0011</b>	<b>B0011</b>	<b>B0011</b>	<b>B0011</b>

#### BOLT KITS ASSEMBLY PARTS LIST

Item	Description	B0011
3	Bolt M30-3.5x195mm	<b>70880</b>
4	Self Locking Nut M30-3.5	<b>71721</b>
5	Washer Outer Pivot Eye	<b>11388</b>
8	Nut M24 U-Bolt	<b>15175</b>
9	Washer M24	<b>15174</b>
15	Nut M24 Nyloc	<b>71722</b>
19	Bolt M12-1.75x55mm GRD8.8	<b>70657</b>
20	Washer M12 Spring	<b>72012</b>
21	Nut M12 Nyloc	<b>71670</b>
22	Halfnut M20x1.5	<b>71760</b>
23	Washer M22 Spring	<b>72014</b>
	Bolt M24-2.0x210mm GRD10.9	<b>70861</b>
	Bolt M24-2.0x270mm GRD10.9	<b>70865</b>
	Bolt M24-2.0x300mm GRD10.9	-
	Bolt 1/2" UNCx1.75" S Z/PLT	-
	Washer M20 Shakeproof INT Z/PL	-
	Washer 1/2" Spring Rect. Z/PLT	-
	Halfnut 3/4" UNF	-